

## **TIMING A COG STYLE MAGNETO**

**Magneto is set to fire on #1 cylinder.**

**DO NOT MOVE IT**

Rotate Engine so the #1 cylinder is at Top Dead Center Compression, ready to fire. At this point Magneto will not line up with drive cogs in the engine, you must back engine up until cogs line up with Magneto. Carefully slide the Magneto into mounting hole and bolt down tight.

**ENGINE IS READY TO START**