

WHEN MAGNETO IS SET TO FIRE ON #1 CYLINDER

DO NOT MOVE IT

- Rotate Engine so the #1 Cylinder is at Top Dead Center compression ready to fire.
- At this point the Magneto will not line up with drive cogs in the engine. You must back engine up until cogs line up with magneto.
- Carefully slide the magneto into mounting hole and bolt down tight.

ENGINE IS READY TO START